

**INSTALLATION INSTRUCTIONS
AIRBAG COMPATIBLE WING
FOR 2008 CHEVY IMPALA
W52IO6A**



NOTE: Carefully review the components below and familiarize yourself with these parts. If there are any missing parts, call (317) 579-6680 and ask for "Customer Service", or circle the missing part on the sheet and fax it to:

"Pro-Gard Customer Service"
@ (317) 579-6681



**Wing Mount Support
(3P928) Qty. 6**



**Driver & Passenger Wings
With Supports Assembled**

**Airbag wing
and Support Bracket
Installed.**



Airbag wing installation

1. The hardware to mount the wings will be included in this wing kit. See the hardware descriptions below.
2. Attach the brackets to the wing by placing the long leg of the bracket against the inside surface of the wing as shown above. Start the bolts 3X92 from the opposite side of the wing so the nut will tighten against the bracket. When complete, mount the assembly to the front side of the partition with the remaining 3X92 bolts and tighten all fasteners. Be sure the wing is free to move inward toward the center of the vehicle.



1/4-20-WHIZ WASHER
3X16Z
(12) EACH



1/4-20X 1/2 CARRIAGE
BOLT
3X92
(12) EACH

IF THERE ARE ANY QUESTIONS OR CONCERNS PLEASE CONTACT

PRO-GARD PRODUCTS, LLC
PHONE: 317-579-6680