


INSTALLATION GUIDE

*2019 - CURRENT
CHEVROLET SILVERADO
REAR WINDOW GUARD
RWG54SIL19*


Pro-gardTM
PRODUCTS LLC.

STRONG. RELIABLE. SECURE.

**THESE COMPONENTS ARE REQUIRED
TO INSTALL THE REAR WINDOW GUARD**



RWG54SIL19



HARDWARE KIT

- I. The following tools will be required to complete the installation**
- II. Read all instructions and refer to the second to last page to ensure all parts were received**

- | | | |
|----------------------------|----------------|-----------------------|
| A. 7/16" socket | D. 1" hole saw | G. Centering punch |
| B. 7/16" open ended wrench | E. 10mm socket | H. 3/16" drill bit |
| C. 3/16" Allen wrench | F. 7mm socket | I. Trim removal tools |

WARNING: Locate all wiring, fuel lines, brake lines, coolant lines, and refrigerant lines before drilling any holes or installing any self-drilling fasteners.

III. Preparation

- A. Remove rear seat. (Fig. 1)
- B. Remove upper C-pillar trim by prying with trim tool.



Figure 1

X. Install Rear Window Guard

- A. Remove lower tether eyelet clip using 7mm socket and remove trim. (Fig. 2)




Figure 2

- B. Locate upper bracket [3RWG541914] by inserting threaded locator in seat belt hole feature and re-fasten the eyelet clip over the bracket to secure. (Fig. 3)
- C. Drive self drilling screw [3X162] at the rearward hole. Use 7/64" dia drill for pilot hole if required.
- D. Re-install upper C-pillar trim.
- E. Repeat for the opposite side.




Figure 3

- I. Loosen headliner above rear window to access vehicle sheet metal.
- J. Locate (2) upper headliner brackets [3RWG541903] by centering bracket tabs with surface between oval features and fasten with (2) self-drilling screws [3X162] (Fig. 4)
- K. Re-install headliner and upper trim.




Figure 4

- L. Remove lower (3) 18mm OEM bolts and seat back/tie down OEM brackets.
- M. Install frame [RWG54SIL19] by aligning to lower bolt holes and fastening loosely using the OEM bolts.(Fig. 5)
- N. Drive (4) 1-1/2" long self drilling screws [3X47] into upper corner brackets thru trim. (Fig. 6)




Figure 5

- O. Drive (2) self drilling screws [3X162] thru headliner upper brackets at center.(Fig. 6)
- P. Remove lower OEM bolts, re-install tie down brackets over frame brackets and tighten lower OEM bolts. (Fig 6)
- Q. Re-install lower seat assembly without seat back and leave out first bolt right of seat split.




Figure 6

XII. Finishing Steps

- A. Ensure all fasteners installed in this installation are tight and all panels secure..

Installation complete

If you have any problems with this installation or have any questions please call (800-480-6680) and ask for technical assistance.

PARTS LIST		
ITEM	QTY	PART NUMBER DESCRIPTION
1	1	3RWG541901-A FRAME WELDMENT
2	2	3RWG541903-A UPPER FASTENING BRACKET
3	1	3RWG541914-A UPPER FASTENING BRACKET ASSY, PS
4	1	3RWG541915-A UPPER FASTENING BRACKET ASSY, DS
5	4	3X47 #14 x 1-1/2" SELF DRILLING HEX HEAD SCREW
6	6	3X162 #14 x 3/4" SELF DRILLING HEX HEAD SCREW

