

INSTALLATION GUIDE



WBP57NPT15
POLYCARBONATE WINDOW ARMOR
FOR OEM DOOR PANEL
2015 - 2020 CHEVROLET TAHOE

Pro-gard[™]
PRODUCTS LLC.


STRONG | RELIABLE | SECURE

pro-gard.com
800.480.6680

THESE COMPONENTS ARE REQUIRED
TO INSTALL THE PRO-GARD WINDOW ARMOR



WBP57NPT15
WINDOW ARMOR



HARDWARE KIT

I. Refer to the diagram above to verify all parts were received.

II. The following tools will be required to complete the installation:

1. 7/64" drill bit W/ driver
2. Drill with standard #2 Philips driver

III. Read all instructions carefully before starting the assembly process.

NOTE: *if using Pro-Gard ABS door panel use WBP57T15.*

IV. Window Armor Installation

- A. Remove the OEM window trim that protects the top and sides of the window frame. Discard the trim.

NOTE: *It may be necessary to drill a 7/64" pilot hole before using the supplied self-tapping screws.*

- B. From inside of the door place the window armor into the corresponding window opening.
- C. Slide the steel brackets into the door panel until the lower flange of the polycarbonate is resting on top of the OEM door panel.

D. Center the outer window armor frame with the OEM sheet metal.

E. Secure the window armor to the OEM sheet metal, using the provided 3X72 self-tapping screws.

F. Repeat the process for the opposite side.

IV. Installation Complete

4WBP57NP15		
ITEM	QTY	DESCRIPTION
1	1	POLY WINDOW ARMOR DRIVERS SIDE
2	1	POLY WINDOW ARMOR PASSENGER SIDE

4WBP57NP15		
ITEM	QTY	DESCRIPTION
3	24	8-32 X 5/8 PHIL PAN HD MS

