

## G5040UT to G5047UT Gun Rack Conversion

1. Remove the gun lock from the main assembly
2. Add the (2) provided spacers to the underside of the lock and secure into previously located slots.
3. Remove the forearm bracket located on the top of the gun lock and replace with the longer bracket included in the kit.
4. Remove trigger guard and charging handle bracket from the main assembly. Replace items with 3G201 and supplied 'L' bracket.
5. Ensure all bolts are tight.

