



I. Installing Partition Buckles

- A. Locate an area on the Partition Mounting Plate to mount the Partition Buckle in a similar position shown above. Then mark the locations where the buckle will go using the dimensions provided above. Those are the hole locations, which will be drilled out using a 5/16" drill bit.
- B. Then, slide the metal flange protruding from the bottom of the buckle into the first hole. Align the hole in the Partition Buckle with the remaining hole in the Mounting Plate, then insert the 3X36 carriage bolt and secure it with the 3X16Z whiz nut.

INSTALLATION GUIDE PARTITION BUCKLE

Pro-gard[™]
PRODUCTS LLC.

STRONG | RELIABLE | SECURE

pro-gard.com
800.480.6680