

# ***INSTALLATION GUIDE***


**2020+ FORD INTERCEPTOR UTILITY  
CARGO STORAGE DRAWER MOUNT  
4CSD47UINT20FS  
4CSD47UINT20**

**Pro-gard<sup>TM</sup>**  
PRODUCTS LLC.

**STRONG. RELIABLE. SECURE.**

**THESE COMPONENTS ARE REQUIRED**  
**TO INSTALL THE ALUMINUM STORAGE DRAWER MOUNTS**

This system requires the  
barrier to be previously installed .



**I. The following tools will be required to complete the installation**

- |                 |              |
|-----------------|--------------|
| A. SAE Sockets  | C. Torx Bits |
| B. SAE Hex Keys | D. Jig Saw   |

**II. Read all instructions and refer to last page to ensure all parts were received**


---

**WARNING:** *Locate all wiring, fuel lines, brake lines, coolant lines, or refrigerant lines before drilling any holes or installing any self-drilling fasteners.*

---

**III. Cargo Area Preparation**


- A. Remove the cargo floor from above the spare tire.
- B. Using an 8mm socket remove the two bolts attaching the rear sections of foam to the vehicle.
- C. Remove the two sections of foam (see Figure 1 below)
- D. *If installing with existing Barrier, skip to section VI.*
- E. Using a T55 Torx driver, remove the two bolts from the remaining front section of the cargo floor.
- F. Remove the front section of the cargo floor
- G. Unplug the OEM upfitter power terminal and feed all wires to the underside of the foam
- H. Remove the front section of foam.



**Figure 1**

#### **IV. Install Front Barrier Support Bracket [4CSD47UINT20FS only]**

- A. Remove the two front driver side OEM bolts from the OEM X-brace using an 18mm socket (see Figure 2 below).
- B. Place (1) support bracket [3BAR472011] on the top of the X-brace angled towards the rear of the vehicle. Set the front edge of the bracket just behind the front edge of the X-brace. Reinstall the OEM bolts and torque to factory specifications.
- C. Repeat steps A and B on passenger side.



**Figure 2**

## V. Reinstall the Front Portion of Load Floor and Foam

- A. Test fit the front section of foam and mark the locations that need to be timed to fit around the Lower Front Brackets
- B. Trim and reinstall the front section of foam
- C. Place the front section of the load floor into the vehicle and mark the locations where the Lower Front Brackets (2) [3BAR472011] contact the underside of floor.
- D. Using a jigsaw, cut the necessary clearance to allow the front section of the load floor to sit in place.
- E. Reinstall the front section of the load floor and install the two fasteners that secure it using a T55 Torx driver (see Figure 3 below).



Figure 3

## VI. Partially Remove Barrier Brace

- A. *If being installed without Barrier, skip to next section*
- B. Remove the bolt that secures the brace to it's mounting bracket (see Figure 4).
- C. Swing brace out of the way.




Figure 4

## VII. Install CSD Rear Support Brackets

- Remove the two rear driver side bolts from the OEM X-brace with an 18mm socket.
- Place [3CSD472002] over the holes, fitting circular cutout over the pin in the OEM X-brace. If the barrier is present [3CSD472002] will set on top of the barrier bracket.
- Reinstall the OEM bolts and torque to factory specifications.
- Repeat steps A-C for the passenger side with passenger side bracket [3CSD472003].




Figure 5

## VIII. Install CSD Front Support Brackets

- If installing with existing Barrier, remove (2) [3X611] 5/16-18 x 7/8" bolts securing Barrier to Barrier Support Bracket (See Figure 6).
- Place the drivers side bracket [3CSD472000], on top of support bracket [3BAR472011] and line up the holes. \*\*\*If installing with Barrier, this bracket will sit on top of Barrier bottom edge
- Insert (2) [3X611] screws and tighten.




Figure 6

## IX. Join Front and Rear Brackets

- A. Join the Front Support Bracket [3CSD472000] to the Rear Support Bracket [3CSD472002] with (2) [3X149] 5/16-18 x 3/4" screws, (2) [3X12] 1/4" flat washers, and (2) [3X619] 5/16-18 nuts utilizing the joining tabs.
- B. If applicable reattach the barrier brace to Barrier Support Brace and the CSD Rear Support Bracket using the nuts and bolts removed in section VI .
- C. Repeat on the opposite side with the passenger side bracket [3CSD472001].




Figure 7


## X. Reinstall OEM Components

- A. Place two rear sections of foam in vehicle and fasten with the (2) bolts removed in step 1 with an 8mm socket.
- B. Place rear portion of load floor in vehicle

### Installation complete

If you have any problems with this installation or have any questions please call (800-480-6680) and ask for technical assistance.


PARTS LIST		
ITEM	QTY	PART NUMBER DESCRIPTION
1	2	3BAR472011 BARRIER SUPPORT BRACKET WELDMENT
2	1	3CSD472000 DS FRONT CSD MOUNT WELDMENT
3	1	3CSD472001 PS FRONT CSD MOUNT WELDMENT
4	1	3CSD472002 DS REAR CSD MOUNT
5	1	3CSD472003 PS REAR CSD MOUNT
6	1	4CSD472098 FS CSD MOUNT KIT HARDWARE



**3CSD47UINT20FS**



PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	3CSD472001	PS FRONT CSD MOUNT WELDMENT
2	1	3CSD472000	DS FRONT CSD MOUNT WELDMENT
3	1	3CSD472002	DS REAR CSD MOUNT
4	1	3CSD472003	PS REAR CSD MOUNT
5	1	4CSD472098	FS CSD MOUNT KIT HARDWARE



4CSD47U1NT20